




Kit 1624

HONDA CR-Z, 3-dr Hatchback, 10-16 / *11-17


*North America










754 Rapid System
480R Rapid Traverse (North America)




480 Traverse (North America)







1





2





754 Rapid System
480R Rapid Traverse
(North America)



x4





x4



x4




480 Traverse
(North America)




x4

3




754 Rapid System



HONDA CR-Z, 3-dr Hatchback, 10-16 / *11-17

X

31



HONDA CR-Z, 3-dr Hatchback, 10-16 / *11-17

Y

26,5

3




480R Rapid Traverse



480 Traverse



(North America)




HONDA CR-Z, 3-dr Hatchback, 10-16 / *11-17

X inch

X mm

37 7/8"

961 mm



HONDA CR-Z, 3-dr Hatchback, 10-16 / *11-17


Y inch

Y mm

36 1/8"

916 mm



4




5

HONDA CR-Z, 3-dr Hatchback, 10-16 / *11-17


SRA







A





B




C




6



	X mm	Y mm	Z mm	X inch	Y inch	Z inch
HONDA CR-Z, 3-dr Hatchback, 10-16 / *11-17	80 mm	610 mm	460 mm	3 1/8"	24"	18 1/8"



7



GB/US	Tighten alternately
D	Die Schrauben abwechselnd anziehen
F	Serrer alternativement chaque côté
NL	Afwisselend aan de linker- en de rechterkant aandraaien
I	Alternare il serraggio delle viti
E	Apertar alternativamente
PT	Aperte alternadamente
S	Dra åt växelvis
FIN	Kierrä vuorotellen
EST	Pinguldage vaheldumisi
LAT	Pielveiciet pamišus
LIT	Užsukinėkite pakaitomis
PL	Śruby dokręcaj naprzemiennie
RU	Загтягивайте попеременно





CZ	Pokręťta багаžníka dokręcaj naprzemiennie.
SK	Dofahujte striedavo
SLO	Privijajte izmenično.
HR	Naizmjenočno zategnite
HU	Egymástól függetlenül szorítandó
GR	Σφιγίγες εναλλάξ
TR	Dönüşümlü sıkın

中文 交替拧紧



한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันในแบบสลับ




≈ 3 Nm






8



x1
17 mm





THULE
SWEDEN
**ONE
KEY
SYSTEM**



		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		



WW ▶ Thule Sweden AB, Box 69, 330 33 Hillerstorp, SWEDEN
NA ▶ Thule Inc., 42 Silvermine Road, Seymour, Connecticut 06483, USA

info@thule.com
customer.service@thule.com

www.thule.com